

**Function 1:**

**PB 1:** On/OFF P3 – Led shows the feedback ( On = LED ON Off = LED Off)

**Function 2:**

**PB 2:** On/OFF L2&L3 - Led shows the feedback ( On = LED ON Off = LED Off)

**Function 3:**

**PB 3:** On/OFF P1 – Led shows the feedback ( On = LED ON Off = LED Off)

**Function 4:**

**PB 4:** On/OFF L1 - Led shows the feedback ( On = LED ON Off = LED Off)

**Function 5:**

**PB 5:** On/OFF P2 – Led shows the feedback ( On = LED ON Off = LED Off)

**Function 6:**

**PB 6:** Moves the shutter to 30 % height, and the slats to 100% (closed).

**Function 7:**

**PB 7:** Central ON

- P1: ON
- P2: ON
- P3: On
- L1: ON
- L2: On
- L3: On
- L5: ON
- L6: ON
- Shutter: UP (0%)

**Function 8:**

- PB 8: Central Off
- P1: OFF
- P2: OFF
- P3: OFF
- L1: OFF
- L2: OFF
- L3: OFF
- L5: OFF
- L6: OFF
- Shutter: Down (100%)

**SW 1 Schneider**

Tegn:	KNX FUNCTION 3 WS 2015		
Dato:	08.08.2015		
Rev:	0	08.08.2015	
DRAWN BY			
Team 2			
FILENAME			
KNX FUNCTION 3.VSD			

**Function 9:****PB 5:**

When you press PB5

Immediate: L6 ON

After 3 sec: L6 Off

L5 ON

After 6 sec: L5 OFF

SW 2 Jung 4093

**Function 10:****PB 1:**

Short push: L1:ON

Long press (longer than 4 sec): L2&L3: ON

LED:

During presence from PIR ON

During NO presence from PIR OFF

**Function 11:****PB 2:**

Short push: L1:ON

Long press (longer than 4 sec): L2&L3: ON

LED:

During presence from PIR ON

During NO presence from PIR OFF

**Function 12:****PB 3 :**

Short push: L4 ON

Long push: L4 Dim Up

Led shows the feedback of L4 ( On = LED ON Off = LED Off)

**Function 13:****PB 4 :**

Short push: L4 OFF

Long push: L4 Dim Down

Led shows the feedback of L4 ( On = LED ON Off = LED Off)

Tegn:	KNX FUNCTION 3 WS 2015		
Dato:	08.08.2015		
Rev:	0	08.08.2015	
DRAWN BY			
Team 2			
FILENAME			
KNX FUNCTION 3.VSD			

**Function 14:****SW3 P1:**

ON: Activates Wind alarm:

Shutter moves UP, and can't be controlled by other switches.

OFF: Deactivates Wind alarm:

Can then be controlled by other switches again.

**SW3 P2:**

No function


**Function 15:****SW3 P3:**

ON: Activates fire alarm:

L2 & L3 blinks ON/OFF, and can't be controlled by other switches.

OFF: Deactivates fire alarm:

Stops blinking, and can be controlled by other switches again.

**Function 16:****SW4 P1:**

Short press: Step/stop UP

Long press: Move shutter UP

**Function 17:****SW4 P2:**


Short press: Step/stop DOWN

Long press: Move shutter DOWN

**Function 18:****SW4 P3**

Short push: Toggle L4 ON/Off


Long push: Toggle L4 Dim Up/Down

**Function 19:****PIR:**


When motion the PIR starts constant light control:

The setpoint is 600 lux.

When there is no motion the light is turned off after 10 seconds.

**Function 20:****P2:**

If the power exceeds 100 W, P1 shall turn off after 5 seconds.



Tegn:	KNX FUNCTION 3 WS 2015		
Dato:	08.08.2015		
Rev:	0	08.08.2015	
DRAWN BY			
Team 2			
FILENAME			
KNX FUNCTION 3.VSD			